



SWELL
PEDAL




FOOT
SWITCH

HX3
SOUND ENGINE




MIDI
IN 1




MIDI
IN 2




9V DC
-G+




BASS



MAIN




ROTARY
SIM L




ROTARY
SIM R



USB
CONFIG




MIDI
OUT



HEAD
PHONE



ROTARY
STATUS



EXTERNAL
ROTARY

www.**KEY**
BOARD
PARTNER.DE