



TO XB2 11 PIN LESLIE CONN
 Connection to 11 pin Leslie
 pin 8 (slow)
 pin 7 (fast)
 pin 6 (power)
 pin 5 (common)
 pin 1 (rotary)
 pin 4 (Gnd)
 pin 2 (stationary)
 Set HX3 JP6 to STEREO